

Phones local dial plan

This page reorganizes the operational steps for **Phones local dial plan**.

Most if not any phone has a local dial plan, a way to filter what is entered in the keypad. They are used to speed up the dialing, placing the call when a complete number is dialed, saving the time to press the "dial" button, but most of the time, they are just annoying not letting us dial what we want. Here a small guide to setting up the correct dial plan for most phones

Grandstream

- x means any digit from 0-9
- X means any digit and any letter from 0-9 and A-Za-z
- + means repetition
- \ is escape character

```
{ x+|-X+ | \#x+|-X+ | x+ | \+x+ | *x+ | *xx*x+ }
```

Current Verification

After applying the change, verify the related MiRTA PBX page, the Asterisk logs, and the relevant Status menu entry. Recheck tenant selection before testing tenant-specific behavior.

Revision #3

Created 2026-06-02 21:59:56 UTC by Admin

Updated 2026-06-02 22:00:38 UTC by Admin