


# Overview

The **DISAs** page creates DISA access points for authenticated outbound calling through the PBX. Open it from **Configuration > More Configuration > DISAs**.

The page works against the tenant currently selected in the top bar. The screenshots and demo rows were captured in the **Canistracci OIL** tenant.



DISAs list page in the Canistracci OIL tenant.

## Working with objects

Task	How to do it
Add	Select the New DISA action, complete the form, and select Save.
Edit	Open the DISA from the list by selecting its name, number, or row action. Change the form and select Save.
Delete	Select the row checkbox and use Delete Selected, or open the DISA and select Delete, then confirm.

## Page functions

Action	Description
New DISA	Opens the creation form for a new disa.
Delete Selected	Deletes the selected rows after confirmation.

## List columns

Column	Description
Name	Display name used in lists and references.
Recording	Recording behavior or recording delivery setting.
PIN	Credential or PIN value. Treat it as sensitive.
Outbound	Object setting shown by the form.
CallerID	Caller ID or caller matching value.

# Demo records

The tenant contains 1 documentation demo record for this page: Docs Demo DISA 1.

# Deleting records

Before deleting a DISA, check references from call flows, destinations, schedules, reports, or provisioning objects. MiRTA PBX asks for confirmation before the delete is submitted.

---

Revision #8

Created 2026-06-02 12:15:28 UTC by Admin

Updated 2026-06-02 16:23:23 UTC by Admin